


■ No. **2012-109** ■ Date: 2013/1/28


Model : **HE800B**

Title : **HE-800B Function**

HE-800B Function



Threading Mode

 Lower Clamp, tension Open
Needle move to right (3mm)




Bobbin Counter Setting

 + 

Production Counter Setting

 + 



Cycle Program Setting

  C01 → 


Program Copy



Bobbin Winding

 + 



Writing or Reading of Data



r 1: Read All Parameter
w 2: Write All Parameter
r 3: Read All Memory Switch
w 4: Write All Memory Switch
r 5: Read All Data
w 6: Write All Data
r 7: Write Error Log





Special function Setting

Initialization

 + 






1: Program & Cycle Program
2: Memory Switch
3: All Clear

Protect Setting A

   + 



OFF	No Protecting
LEVEL	Strong<----->Weak
1,2,3,4	1 <-----> 4
LEVEL5	Individual Setting

Protect Setting B



 +    + 

Enable to select protect setting with SD card. Once set with SD card disable to change protect setting without SD card.



In-put Checking

 + 



Out-put Checking

 + 

Comfirm Software Version



 + 


Maintenance Information

 + 

1: Acumulated Number of Stitches
2: Acumulated Number of Error
3: Value of Motor reference Potision Setting

Error Log




 + 

 appear acumulated number of stitches (X10)

Memory SW (Operator)






Memory SW (ALL)

  + 





# 000-099	Clamping Foot & Pedal
# 100-199	Machine Motor
# 200-299	Feed
# 300-399	Operation Panel
# 400-499	Sewing Program
# 500-599	Device
# 600-699	Error Processing
# 700-799	Maintenance
# 800-899	Spec. & Destination


Machine's Serial No.

Top Secret (brother staff only)




Software Version-up

 +   + 



1: Main CPU (Mn)
2: Motor CPU (Mt)
3: Panel CPU (PL)

Motor Reference Position

1: One rotation by hand (check signal)
2: Press Enter after confirm needle bar high
-2: distance between needle plate and bottom of needle bar 43.2mm (5.3mm lowered from highest point)
-3: distance between needle plate and bottom of needle bar 42.4mm (5.3mm lowered from highest point)

Home Position Setting



Setting of Pedal Position



Protect Function

Setting Item	No.	Protect Function															
		OFF	1	2	3	4	5										
							1	2	3	4	5	6	7	8	9	10	11
Initialize			x	x	x	x	x										
Memory SW (Operator)			x	x				x									
Memory SW (Mechanic)			x	x	x				x								
Program No.			x	x	x					x							
Sewing Speed			x	x	x	x					x						
Editing Program			x	x	x							x					
Program Copy			x	x	x							x					
Cutter Operation			x	x	x								x				
Editing Product Counter			x	x										x			
Editing Bobbin Counter			x	x											x		
Re-sewing from stop			x	x												x	
Home Position Adjusting			x														x
Motor Reference Position			x														x
Adjusting Pedal Position			x														x