

Web Connect Guide



Applicable models

This User's Guide applies to the following models:

DCP-J4110DW, MFC-J2510/J4410DW/J4510DW/J4610DW

Definitions of notes

We use the following icon throughout this user's guide:

NOTE	Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.
-------------	---

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.

Brother is a trademark of Brother Industries, Ltd.

FLICKR is a registered trademark of Yahoo! Inc.

GOOGLE DOCS, PICASA and PICASA Web Albums are trademarks of Google, Inc. Use of these trademarks are subject to Google Permissions.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

Macintosh is a trademark of Apple Inc., registered in the United States and other countries.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

Any trade names and product names of companies appearing on Brother products, related documents and any other materials are all trademarks or registered trademarks of those respective companies.

IMPORTANT NOTE

- Please go to the Brother Solutions Center at <http://solutions.brother.com/> and click Manuals on your model page to download the other manuals.
- Not all models are available in all countries.
- For DCP users; This documentation is for both MFC and DCP models. Where it says 'MFC' in this user's guide, please read 'MFC-xxxx' as 'DCP-xxxx'.


©2012 Brother Industries, Ltd. All rights reserved.

Table of Contents

1	Introduction	1
	Brother Web Connect Feature.....	1
	Accessible services	2
	Conditions for using Brother Web Connect	3
	Service account	3
	Internet connection	3
	MFL-Pro Suite installation	3
	Proxy server settings	3
	Setting up Brother Web Connect	5
	Step-by-step overview	5
	How to create an account for each of the desired services	6
	How to apply for Brother Web Connect access	6
	How to register and delete accounts on the machine.....	8
2	Download	12
	Downloading and printing images.....	12
	How to change print settings	16
	Downloading and saving images to a memory card or USB Flash memory drive connected to your machine	18
3	Upload	22
	Scanning and uploading documents.....	22
	How to change scan settings.....	24
	Uploading images saved on the memory card or USB Flash memory drive	26
4	Shortcut Settings (For MFC-J2510/J4510DW)	28
	Adding Web Connect Shortcuts.....	28
	How to change Shortcuts	29
	How to edit Shortcut Names.....	29
	How to delete Shortcuts	29
	How to recall Shortcuts.....	29
A	Troubleshooting	30
	Error messages	30

Brother Web Connect Feature

Certain websites provide services that allow users to upload and view images and files on the website. Your Brother machine can scan images and upload them to these services, and also print images that are already uploaded to these services.



1 Photos and documents

Accessible services

The following services can be accessed from your Brother machine:

■ Picasa Web Albums™

Picasa Web Albums™ is an online photo sharing service. Images can be uploaded, organized into albums, and shared with other users.

URL: <http://picasaweb.google.com/>

■ Google Docs™

Google Docs™ is an online document editing and sharing service.

URL: <http://docs.google.com/>

■ Flickr®

Flickr® is an online photo sharing service. Images can be uploaded, organized into albums, and shared with other users.

URL: <http://www.flickr.com/>

■ Facebook™

Facebook™ is a social networking service that also allows images to be uploaded and shared with other users.

URL: <http://www.facebook.com/>

■ Evernote®

Evernote® is an online file storage and managing service.

URL: <http://www.evernote.com/>

■ Dropbox

Dropbox is an online file storage, sharing and file synchronization service.

URL: <http://www.dropbox.com/>

For details about any of these services, refer to the respective service's website.

The following table describes which types of files can be used with each Brother Web Connect feature:

Accessible Services	Picasa Web Albums™	Google Docs™	Flickr®	Facebook™	Evernote®	Dropbox
Download and print images or save them to media	JPEG	JPEG, PDF	JPEG	JPEG	JPEG, PDF	JPEG, PDF
Upload scanned images	JPEG	PDF	JPEG	JPEG	JPEG, PDF	JPEG, PDF
Upload images saved on media	JPEG	—	JPEG	JPEG	JPEG	JPEG

NOTE

(For Hong Kong, Taiwan and Korea)

Brother Web Connect supports only file names written in English. Files named in the local language will not be downloaded or uploaded.

Conditions for using Brother Web Connect

Service account

In order to use Brother Web Connect, you must have an account with the desired service. If you do not already have an account, use a computer to access the website of the service and create an account.

Internet connection

In order to use Brother Web Connect, your Brother machine must be connected to a network that has access to the Internet through either a wired or wireless connection. See the Quick Setup Guide to connect and configure the machine appropriately.

For network setups that use a proxy server, the machine must also be configured to use a proxy server (see *Proxy server settings* on page 3).

NOTE

A proxy server is a computer that serves as an intermediary between computers without a direct Internet connection, and the Internet.

MFL-Pro Suite installation

The initial installation of Brother Web Connect requires a computer that has access to the Internet and has Brother MFL-Pro Suite installed. Follow the steps outlined in the Quick Setup Guide to install the MFL-Pro Suite (from the supplied installer CD-ROM) and configure the machine to be able to print over your wired or wireless network.

Proxy server settings

If the network uses a proxy server, the following proxy server information must be configured on the machine:

- Proxy server address
- Port number
- User name
- Password

For MFC-J2510/J4510DW

- 1 Press .
- 2 Press All Settings.
- 3 Swipe up or down, or press ▲ or ▼ to display Network.
Press Network.

- 4 Swipe up or down, or press ▲ or ▼ to display Web Connect Settings.
Press Web Connect Settings.
- 5 Press Proxy Settings.
- 6 Swipe up or down, or press ▲ or ▼ to display Proxy Connection.
Press Proxy Connection.
- 7 Press On.
- 8 Press the option that you want to set, and then enter the proxy server information.
Press OK.
- 9 Press .

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Press Settings.
- 2 Press ▲ or ▼ to display Network.
Press Network.
- 3 Press ▲ or ▼ to display Web Connect Settings.
Press Web Connect Settings.
- 4 Press Proxy Settings.
- 5 Press ▲ or ▼ to display Proxy Connection.
Press Proxy Connection.
- 6 Press On.
- 7 Press the option that you want to set, and then enter the proxy server information.
Press OK.
- 8 Press .


Setting up Brother Web Connect

Step-by-step overview

Configure the settings using the following procedure:


Step 1: Create an account with the desired service (see page 6).

Access the service's website using a computer and create an account. (If you already have an account, there is no need to create an additional account.)




Step 2: Apply for Brother Web Connect access (see page 6).

Start Brother Web Connect access using a computer and obtain a temporary ID.



Step 3: Register (on the machine), the account information that is needed to access the desired services (see page 8).

Enter the temporary ID to enable the service on the machine. Specify the account name as you would like it to be displayed on the machine, and enter a PIN if you would like to use one.



The machine can now use the service.

How to create an account for each of the desired services

In order to use Brother Web Connect to access an online service, you must have an account with that online service. If you do not already have an account, use a computer to access the website of the service and create an account. After creating an account, log on and use the account once with a computer before using the Brother Web Connect feature. Otherwise, you may not be able to access the service using Brother Web Connect.

If you already have an account, there is no need to create an additional account.

Continue with the next procedure, *How to apply for Brother Web Connect access* on page 6.

NOTE

You do not need to create an account if you will use the service as a guest. You can only use certain services as a guest. If the service you want to use does not have this option, you must create an account.

How to apply for Brother Web Connect access

In order to use Brother Web Connect to access online services, you must first apply for Brother Web Connect access using a computer that has Brother MFL-Pro Suite installed:

- 1 Turn on your computer.
- 2 Access the Brother Web Connect application web page.

■ Windows®

If you have already installed MFL-Pro Suite, choose  / **All Programs / Brother / MFC-XXXX** (where XXXX is your model name) / **Brother Web Connect**.

The web browser will start and access the application page.

NOTE

You can also access the page directly by typing "<https://moi.bwc.brother.com/portal/>" into your web browser's address bar.

■ Macintosh

If you have already installed MFL-Pro Suite, double-click **Macintosh HD / Applications / Brother / Utilities / Brother Web Connect**.

The web browser will start and access the application page.


NOTE

You can also access the page directly in the following ways:

- From the supplied installer CD-ROM
 - 1 Put the supplied installer CD-ROM into your CD-ROM drive. Double-click the **Brother Support** icon.
 - 2 Click the **Brother Web Connect** icon.
- From your web browser


Type "<https://moi.bwc.brother.com/portal/>" into your web browser's address bar.

3 Choose the desired service.



4 Follow the on-screen instructions and apply for access.

When finished, your temporary ID will be displayed. This temporary ID is needed when registering accounts to the machine, so make a note of the ID. The temporary ID is valid for 24 hours.



5 Close the web browser.

Continue with the next procedure, *How to register and delete accounts on the machine* on page 8.

How to register and delete accounts on the machine

Enter the account information and configure the machine so that it can access the service:

Register an account

For MFC-J2510/J4510DW

- 1 Before you register an account, confirm that the correct time and date are set on the machine's control panel. See the Quick Setup Guide included with your machine for instructions on setting the correct time and date.
- 2 Swipe left or right, or press ◀ or ▶ to display the `More` screen.
- 3 Press `Web`.
Information regarding the Internet connection is displayed on the machine's LCD. Read the information and press `OK`.
- 4 You will be asked if you want to display this information again in the future.
Press `Yes` or `No`.
- 5 Choose the desired service.
- 6 If information regarding Brother Web Connect is displayed, press `OK`.
- 7 Press `Register/Delete Account`.
- 8 Press `Register Account`.
- 9 A message is displayed prompting you to enter the temporary ID you received when you applied for Brother Web Connect access.
Press `OK`.
- 10 Enter the temporary ID.
Press `OK`.

NOTE

An error message will appear on the LCD if the information you entered does not match the temporary ID you received when you applied for access or if the temporary ID has expired. Either enter the temporary ID correctly or apply for access again and receive a new temporary ID (see *How to apply for Brother Web Connect access* on page 6).

- 11 A message is displayed, prompting you to enter a name for the account as you want it to be displayed on the LCD.
Press `OK`.
- 12 Enter the name using the buttons on the LCD.
Press `OK`.

- 13 Do one of the following:
 - To set a PIN for the account, press **Yes**. Enter a four-digit number and press **OK**. (A PIN prevents unauthorized access to the account.)
 - If you do not want to set a PIN, press **No**.
- 14 You will be asked if you want to register the account information you entered.
 - Press **Yes** to register.
 - Press **No** to enter the information again. Go back to step 10.
- 15 Account registration is complete.
Press **OK**.
- 16 Press .

NOTE

Up to 10 accounts can be registered on the machine.

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Before you register an account, confirm that the correct time and date are set on the machine's control panel. See the Quick Setup Guide included with your machine for instructions on setting the correct time and date.
- 2 Press **▲** or **▼** to display **Web**.
Press **Web**.
- 3 Information regarding the Internet connection is displayed on the machine's LCD. Read the information and press **OK**.
- 4 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 5 Choose the desired service.
- 6 If information regarding Brother Web Connect is displayed, press **OK**.
- 7 Press **Register/Delete**.
- 8 Press **Register Account**.
- 9 A message is displayed prompting you to enter the temporary ID you received when you applied for Brother Web Connect access.
Press **OK**.

- 10 Enter the temporary ID.
Press **OK**.

NOTE

An error message will appear on the LCD if the information you entered does not match the temporary ID you received when you applied for access or if the temporary ID has expired. Either enter the temporary ID correctly or apply for access again and receive a new temporary ID (see *How to apply for Brother Web Connect* access on page 6).

- 11 A message is displayed, prompting you to enter a name for the account as you want it to be displayed on the LCD.
Press **OK**.
- 12 Enter the name using the buttons on the LCD.
Press **OK**.
- 13 Do one of the following:
- To set a PIN for the account, press **Yes**. Enter a four-digit number and press **OK**. (A PIN prevents unauthorized access to the account.)
 - If you do not want to set a PIN, press **No**.
- 14 You will be asked if you want to register the account information you entered.
- Press **Yes** to register.
 - Press **No** to enter the information again. Go back to step 10.
- 15 Account registration is complete.
Press **OK**.
- 16 Press .

NOTE

Up to 10 accounts can be registered on the machine.

Delete an account

For MFC-J2510/J4510DW

- 1 Swipe left or right, or press ◀ or ▶ to display the **More** screen.
- 2 Press **Web**.
If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 3 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 4 Choose the desired service.

- 5 Press Register/Delete Account.
- 6 Press Delete Account.
- 7 Press the accounts that you want to delete. The selected accounts will be indicated by check marks.
- 8 Press OK.
- 9 You will be asked to confirm your selections.
Press Yes to delete.
- 10 Account deletion is complete.
Press OK.
- 11 Press .

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Press  or  to display Web.
Press Web.
- 2 If information regarding the Internet connection is displayed on the machine's LCD, read the information and press OK.
- 3 You will be asked if you want to display this information again in the future.
Press Yes or No.
- 4 Choose the desired service.
- 5 Press Register/Delete.
- 6 Press Delete Account.
- 7 Press the accounts that you want to delete. The selected accounts will be indicated by check marks.
- 8 Press OK.
- 9 You will be asked to confirm your selections.
Press Yes to delete.
- 10 Account deletion is complete.
Press OK.
- 11 Press .

Downloading and printing images

Images that have been uploaded to the service can be downloaded directly to the machine and printed. Images that other users have uploaded for sharing can also be downloaded as long as you have viewing privileges for those images.

Certain services allow guest users to view images that are public. When accessing as a guest user, you can view images for which the owner has made public (i.e., there are no viewing restrictions).

For information about services and supported features, see *Accessible services* on page 2.

NOTE

(For Hong Kong, Taiwan and Korea)

Brother Web Connect supports only file names written in English. Files named in the local language will not be downloaded.

For MFC-J2510/J4510DW

- 1 Swipe left or right, or press ◀ or ▶ to display the **More** screen.
- 2 Press **Web**.
If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 3 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 4 Choose the desired service.
- 5 Do one of the following:
 - To log on to the service with your account, swipe up or down, or press ▲ or ▼ to display your account name, and press it. Go to step 6.
 - To access the service as a guest user, swipe down or press ▼ to display **Use Service as a Guest User**, and press it. When the information regarding access as a guest user is displayed, press **OK**. Go to step 8.
- 6 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 7 Press **Download**.
- 8 Press **Print**.
Do one of the following:
 - If you logged on to the service with your account, go to step 9.
 - If you accessed the service as a guest user, go to step 10.

- 9 Do one of the following:
 (For Picasa Web Albums™, Flickr® and Facebook™)
 ■ To download your own images from the service, press `Your Album`. Go to step 11.
 ■ To download other users' images from the service, press `Other User's Album`. Go to step 10.
 (For Google Docs™, Dropbox and Evernote®)
 ■ Go to step 11.

NOTE

In order to download other users' images, you must have access privileges to view the corresponding albums or images.

- 10 Using the buttons on the LCD, type the account name of the user whose images you want to download. Press `OK`.

NOTE

Depending on the service, you may have to select the account name from a list of other users that is displayed.

- 11 Swipe up or down, or press ▲ or ▼ to display the desired album ¹, and press it.
 Some services do not require images to be saved in albums. For images not saved in albums, select `Show Unsorted Photos` to select images. Other users' images cannot be downloaded if they are not saved in an album.

¹ An album is a collection of images. However, the actual term may differ depending on the service you use.
 When using Evernote®, you must select the notebook, and then select the note.

- 12 Press the thumbnail of the desired image.
 Confirm the image on the LCD and press `OK`.
 Repeat this step until you have chosen all the images that you want to print (you can select up to 10 images).
- 13 After you have chosen all of the desired images, press `OK`.
- 14 The print settings screen will be displayed. Do one of the following:
 ■ To change print settings, see *How to change print settings* on page 16. After changing the print settings, go to step 15.
 ■ If you do not want to change print settings, press `OK`.
- 15 Press `OK` to print.
 The machine starts downloading and printing the image(s).
- 16 Press .

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Press **▲** or **▼** to display **Web**.
Press **Web**.
- 2 If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 3 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 4 Choose the desired service.
- 5 Do one of the following:
 - To log on to the service with your account, press **▲** or **▼** to display your account name, and press it. Go to step 6.
 - To access the service as a guest user, press **▲** or **▼** to display **Use as a Guest User**, and press it. When the information regarding access as a guest user is displayed, press **OK**. Go to step 8.
- 6 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 7 Press **Download**.
- 8 Press **Print**.
Do one of the following:
 - If you logged on to the service with your account, go to step 9.
 - If you accessed the service as a guest user, go to step 10.
- 9 Do one of the following:
(For Picasa Web Albums™, Flickr® and Facebook™)
 - To download your own images from the service, press **Your Album**. Go to step 11.
 - To download other users' images from the service, press **Other User's Album**. Go to step 10.
 (For Google Docs™, Dropbox and Evernote®)
 - Go to step 11.

NOTE

In order to download other users' images, you must have access privileges to view the corresponding albums or images.

- 10 Using the buttons on the LCD, type the account name of the user whose images you want to download.
Press **OK**.

NOTE

Depending on the service, you may have to select the account name from a list of other users that is displayed.

- 11 Press **▲** or **▼** to display the desired album ¹, and press it.
Some services do not require images to be saved in albums. For images not saved in albums, select *See Unsorted Photos* to select images. Other users' images cannot be downloaded if they are not saved in an album.

¹ An album is a collection of images. However, the actual term may differ depending on the service you use.
When using EVERNOTE®, you must select the notebook, and then select the note.

- 12 Press **▲** or **▼** to display the desired image, and press it.
Confirm the image on the LCD and press **OK**.
Repeat this step until you have chosen all the images that you want to print (you can select up to 10 images).
- 13 After you have chosen all of the desired images, press **OK**.
- 14 The print settings screen will be displayed. Do one of the following:
- To change print settings, see *How to change print settings* on page 16. After changing the print settings, go to step 15.
 - If you do not want to change print settings, press **OK**.
- 15 Press **OK** to print.
The machine starts downloading and printing the image(s).
- 16 Press .

NOTE

(For MFC-J4610DW)

When downloading and printing JPEG files, you cannot print from Tray2.

How to change print settings

The print settings screen is displayed after you have selected the images that you want to print:

For MFC-J2510/J4510DW

Print Quality

- 1 Press **Print Quality**.
- 2 Press **Fine** or **Normal**.
- 3 If you do not want to change any other settings, press **OK**.

Paper Size

- 1 Press **Paper Size**.
- 2 Press the paper size you are using, **Letter**, **A3**, **Ledger**, **Legal**¹, **A4**, **4"x6"** (10x15cm) or **5"x7"** (13x18cm)².
- ¹ PDF files only
² JPEG files only
- 3 If you do not want to change any other settings, press **OK**.

NOTE

You can print using Legal, Ledger and A3 paper only from the manual feed slot.

Paper Type

- 1 Press **Paper Type**.
- 2 Press the paper type you are using, **Plain Paper**, **Inkjet Paper**, **Brother BP71** or **Other Glossy**.
- 3 If you do not want to change any other settings, press **OK**.

NOTE

When downloading and printing PDF files, you can choose only Plain Paper.

Borderless Printing (for JPEG files only)

This feature expands the printable area to the edges of the paper.

- 1 Press **Borderless Print**.
- 2 Press **On** (or **Off**).
- 3 If you do not want to change any other settings, press **OK**.

For DCP-J4110DW, MFC-J4410DW/J4610DW

Print Quality

- 1 Press **Print Quality**.
- 2 Press **Fine** or **Normal**.
- 3 If you do not want to change any other settings, press **OK**.

Paper Size

- 1 Press **Paper Size**.
- 2 Press the paper size you are using, **Letter**, **A3**, **Ledger**, **Legal**¹, **A4**, **4"x6"** (10x15cm) or **5"x7"** (13x18cm)².
¹ PDF files only
² JPEG files only
- 3 If you do not want to change any other settings, press **OK**.

NOTE

You can print using Legal, Ledger and A3 paper only from the manual feed slot.

Paper Type

- 1 Press **Paper Type**.
- 2 Press the paper type you are using, **Plain Paper**, **Inkjet Paper**, **Brother BP71** or **Other Glossy**.
- 3 If you do not want to change any other settings, press **OK**.

NOTE

When downloading and printing PDF files, you can choose only Plain Paper.

Borderless Printing (for JPEG files only)

This feature expands the printable area to the edges of the paper.

- 1 Press **Borderless**.
- 2 Press **On** (or **Off**).
- 3 If you do not want to change any other settings, press **OK**.

Downloading and saving images to a memory card or USB Flash memory drive connected to your machine

JPEG and PDF files can be downloaded from a service and saved directly on media connected to the machine. Images that other users have uploaded for sharing can also be downloaded, as long as you have viewing privileges for those images.

Certain services allow guest users to view images that are public. When accessing as a guest user, you can view images for which the owner has made public (i.e., there are no viewing restrictions).

Make sure there is enough available space on your memory card or USB Flash memory drive.

For details about services and supported features, see *Accessible services* on page 2.

NOTE

(For Hong Kong, Taiwan and Korea)

Brother Web Connect supports only file names written in English. Files named in the local language will not be downloaded.

For MFC-J2510/J4510DW

- 1 Open the media slot cover.
- 2 Insert a memory card or USB Flash memory drive into your machine.
The LCD screen automatically changes.
- 3 Press **Web**.
If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 4 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 5 Choose the desired service.
- 6 Do one of the following:
 - To log on to the service with your account, swipe up or down, or press ▲ or ▼ to display your account name and press it. Go to step 7.
 - To access the service as a guest user, swipe down or press ▼ to display **Use Service as a Guest User**, and press it. When the information regarding access as a guest user is displayed, press **OK**. Go to step 9.
- 7 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 8 Press **Download**.
- 9 Press **Save to MediaCard**.
Do one of the following:
 - If you logged on to the service with your account, go to step 10.
 - If you accessed the service as a guest user, go to step 11.

- 10 Do one of the following:
 (For Picasa Web Albums™, Flickr® and Facebook™)
- To download your own images from the service, press `Your Album`. Go to step 12.
 - To download other users' images from the service, press `Other User's Album`. Go to step 11.
- (For Google Docs™, Dropbox and Evernote®)
- Go to step 12.

NOTE

In order to download other users' images, you must have access privileges to view the corresponding albums or images.

- 11 Using the buttons on the LCD, type the account name of the user whose images you want to download. Press `OK`.

NOTE

Depending on the service, you may have to select the account name from a list of other users that is displayed.

- 12 Swipe up or down, or press ▲ or ▼ to display the desired album ¹, and press it.
 Some services do not require images to be saved in albums. For images not saved in albums, select `Show Unsorted Photos` to select images. Other users' images cannot be downloaded if they are not saved in an album.

¹ An album is a collection of images. However, the actual term may differ depending on the service you use.
 When using Evernote®, you must select the notebook, and then select the note.

- 13 Press the thumbnail of the desired image.
 Confirm the image on the LCD and press `OK`.
 Repeat this step until you have chosen all the images that you want to download (you can select up to 10 images).
- 14 After you have chosen all of the desired images, press `OK`.
- 15 Press `OK` to download.
 The machine starts downloading the image(s).
- 16 Press .

NOTE

- Downloaded files are renamed based on the current date. For example, the first image saved on July 1, would be named 07010001.jpg. Note that the region setting also determines the date format of the file name.
- Images are saved in the "BROTHER" folder, which can be found on the root level of the media.

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Open the media slot cover.

- 2 Insert a memory card or USB Flash memory drive into your machine.
The LCD screen automatically changes.
- 3 Press .
- 4 Press  or  to display **Web**.
Press **Web**.
- 5 If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 6 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 7 Choose the desired service.
- 8 Do one of the following:
 - To log on to the service with your account, press  or  to display your account name, and press it.
Go to step 9.
 - To access the service as a guest user, press  to display **Use as a Guest User**, and press it.
When the information regarding access as a guest user is displayed, press **OK**. Go to step 11.
- 9 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 10 Press **Download**.
- 11 Press **Save to MediaCard**.
Do one of the following:
 - If you logged on to the service with your account, go to step 12.
 - If you accessed the service as a guest user, go to step 13.
- 12 Do one of the following:
(For Picasa Web Albums™, Flickr® and Facebook™)
 - To download your own images from the service, press **Your Album**. Go to step 14.
 - To download other users' images from the service, press **Other User's Album**. Go to step 13.
 (For Google Docs™, Dropbox and Evernote®)
 - Go to step 14.

NOTE

In order to download other users' images, you must have access privileges to view the corresponding albums or images.

- 13 Using the buttons on the LCD, type the account name of the user whose images you want to download.
Press **OK**.

NOTE

Depending on the service, you may have to select the account name from a list of other users that is displayed.

- 14 Press **▲** or **▼** to display the desired album ¹, and press it.
Some services do not require images to be saved in albums. For images not saved in albums, select **See Unsorted Photos** to select images. Other users' images cannot be downloaded if they are not saved in an album.

¹ An album is a collection of images. However, the actual term may differ depending on the service you use.
When using EVERNOTE®, you must select the notebook, and then select the note.

- 15 Press **▲** or **▼** to display the desired image, and press it.
Confirm the image on the LCD and press **OK**.
Repeat this step until you have chosen all the images that you want to print (you can select up to 10 images).
- 16 After you have chosen all of the desired images, press **OK**.
- 17 Press **OK** to download.
The machine starts downloading and printing the image(s).
- 18 Press .

NOTE

- Downloaded files are renamed based on the current date. For example, the first image saved on July 1, would be named 07010001.jpg. Note that the region setting also determines the date format of the file name.
- Images are saved in the "BROTHER" folder, which can be found on the root level of the media.

Scanning and uploading documents

Scanned photos and images can be uploaded directly to a service without using a computer.

For details about services and supported features, see *Accessible services* on page 2.

For MFC-J2510/J4510DW

- 1 Load your document.
- 2 Swipe left or right, or press ◀ or ▶ to display the **More** screen.
- 3 Press **Web**.
If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 4 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 5 Choose the desired service.
- 6 Swipe up or down, or press ▲ or ▼ to display your account name, and press it.
- 7 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 8 If the screen that prompts you to select either upload or download is displayed, press **Upload**.
- 9 If the screen that prompts you to select the upload source is displayed, press **From the Scanner**.
- 10 If the screen that prompts you to specify the file format of the image to be uploaded is displayed, choose the desired file format.

NOTE

When scanning and uploading JPEG files, black and white scanning is not available, and each page is uploaded as a separate file.

- 11 The scan settings screen will be displayed. Do one of the following:
 - To change scan settings, see *How to change scan settings* on page 24. After changing the scan settings, go to step 12.
 - If you do not want to change any settings, press **OK**.
- 12 Press **OK**.
If you placed the document in the automatic document feed (ADF), the machine scans the document and starts uploading.
If you are using the scanner glass, go to step 13.

- 13 When **Next page?** is displayed, do one of the following:
- If there are no more pages to scan, press **No**.
The machine starts uploading the image.
 - To scan more pages, press **Yes** and go to step 14.
- 14 Place the next page on the scanner glass.
Press **OK**.
The machine starts scanning the page. (Repeat steps 13 and 14 for each additional page.)
- 15 Press .

NOTE

- Uploaded images are saved in an album named "From_BrotherDevice".
- For information regarding restrictions, such as the size or number of images that can be uploaded, refer to the respective service's website.

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Load your document.
- 2 Press **▲** or **▼** to display **Web**.
Press **Web**.
- 3 If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 4 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 5 Choose the desired service.
- 6 Press **▲** or **▼** to display your account name, and press it.
- 7 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 8 If the screen that prompts you to select either upload or download is displayed, press **Upload**.
- 9 If the screen that prompts you to select the upload source is displayed, press **From the Scanner**.
- 10 If the screen that prompts you to specify the file format of the image to be uploaded is displayed, choose the desired file format.

NOTE

When scanning and uploading JPEG files, black and white scanning is not available, and each page is uploaded as a separate file.

- 11 The scan settings screen will be displayed. Do one of the following:
- To change scan settings, see *How to change scan settings* on page 24. After changing the scan settings, go to step 12.

- If you do not want to change any settings, press **OK**.

- 12 Press **OK**.
If you placed the document in the automatic document feed (ADF), the machine scans the document and starts uploading.
If you are using the scanner glass, go to step 13.
- 13 When **Next Page?** is displayed, do one of the following:
 - If there are no more pages to scan, press **No**.
The machine starts uploading the image.
 - To scan more pages, press **Yes** and go to step 14.
- 14 Place the next page on the scanner glass.
Press **OK**.
The machine starts scanning the page. (Repeat steps 13 and 14 for each additional page.)
- 15 Press .

NOTE

- Uploaded images are saved in an album named "From_BrotherDevice".
- For information regarding restrictions, such as the size or number of images that can be uploaded, refer to the respective service's website.

How to change scan settings

The scan settings screen is displayed before you scan the documents that you want to upload (see step 11 on page 22 or step 11 on page 23):

For MFC-J2510/J4510DW

Scan Type

- 1 Press **Scan Type** on the scan settings screen.
- 2 Choose **Color** or **B&W**.
- 3 If you do not want to change additional settings, press **OK**.

NOTE

When scanning and uploading JPEG files, black and white scanning is not available, and each page is uploaded as a separate file.

Resolution

- 1 Press **Resolution** on the scan settings screen.
- 2 Choose **100 dpi**, **200 dpi**, **300 dpi** or **600 dpi**.
- 3 If you do not want to change additional settings, press **OK**.

Scan Size

- 1 Press **Scan Size** on the scan settings screen.
- 2 Choose **Letter** or **A4**.
- 3 If you do not want to change additional settings, press **OK**.

NOTE

You may not be able to choose **Letter**, depending on your country.

3

For DCP-J4110DW, MFC-J4410DW/J4610DW

Scan Type

- 1 Press **Scan Type** on the scan settings screen.
- 2 Choose **Color** or **B&W**.
- 3 If you do not want to change additional settings, press **OK**.

NOTE

When scanning and uploading JPEG files, black and white scanning is not available, and each page is uploaded as a separate file.

Resolution

- 1 Press **Resolution** on the scan settings screen.
- 2 Choose **100 dpi**, **200 dpi**, **300 dpi** or **600 dpi**.
- 3 If you do not want to change additional settings, press **OK**.

Scan Size

- 1 Press **Scan Size** on the scan settings screen.
- 2 Choose **Letter** or **A4**.
- 3 If you do not want to change additional settings, press **OK**.

NOTE

You may not be able to choose **Letter**, depending on your country.

Uploading images saved on the memory card or USB Flash memory drive

Images saved on media connected to the machine can be uploaded directly to a service.

For details about services and supported features, see *Accessible services* on page 2.

NOTE

(For Hong Kong, Taiwan and Korea)

Brother Web Connect supports only file names written in English. Files named in the local language will not be uploaded.

3

For MFC-J2510/J4510DW

- 1 Open the media slot cover.
- 2 Insert a memory card or USB Flash memory drive into your machine.
The LCD screen automatically changes.
- 3 Press **Web**.
If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 4 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 5 Choose the desired service.
- 6 Swipe up or down, or press **▲** or **▼** to display your account name, and press it.
- 7 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 8 If the screen that prompts you to select either upload or download is displayed, press **Upload**.
- 9 Press **From the Media Card**.
- 10 Press the thumbnail of the desired image.
Confirm the image on the LCD and press **OK**.
Repeat this step until you have chosen all the images that you want to upload.
- 11 After you have chosen all of the desired images, press **OK**.
- 12 Press **OK**.
The machine starts uploading the image(s).
- 13 Press .

NOTE

- Uploaded images are saved in an album named "From_BrotherDevice".
- For information regarding restrictions, such as the size or number of images that can be uploaded, refer to the respective service's website.

For DCP-J4110DW, MFC-J4410DW/J4610DW

- 1 Open the media slot cover.
- 2 Insert a memory card or USB Flash memory drive into your machine.
The LCD screen automatically changes.
- 3 Press .
- 4 Press  or  to display **Web**.
Press **Web**.
- 5 If information regarding the Internet connection is displayed on the machine's LCD, read the information and press **OK**.
- 6 You will be asked if you want to display this information again in the future.
Press **Yes** or **No**.
- 7 Choose the desired service.
- 8 Press  or  to display your account name, and press it.
- 9 If the PIN entry screen is displayed, enter the four-digit PIN and press **OK**.
- 10 If the screen that prompts you to select either upload or download is displayed, press **Upload**.
- 11 Press **From the Media Card**.
- 12 Press  or  to display the desired image, and press it.
Confirm the image on the LCD and press **OK**.
Repeat this step until you have chosen all the images that you want to upload.
- 13 After you have chosen all of the desired images, press **OK**.
- 14 Press **OK**.
The machine starts uploading the image(s).
- 15 Press .

NOTE

- Uploaded images are saved in an album named "From_BrotherDevice".
- For information regarding restrictions, such as the size or number of images that can be uploaded, refer to the respective service's website.

Adding Web Connect Shortcuts

The settings for the following services can be included in a Web Connect Shortcut:

- Picasa Web Albums™
- Google Docs™
- Flickr®
- Facebook™
- Evernote®
- Dropbox

- 1 If the displayed screen is either *Home* or *More*, swipe left or right, or press ◀ or ▶ to display a Shortcut screen.
- 2 Press  where you haven't added a Shortcut.
- 3 Press *Web*.
- 4 If information regarding the Internet connection is displayed, read the information and confirm it by pressing *OK*.
- 5 Swipe left or right, or press ◀ or ▶ to display the available services, and then press the desired service.
- 6 Press your account.
If the account needs a PIN, enter the PIN for the account using the keyboard on the Touchscreen.
Press *OK*.
- 7 Select the function you want to use.

NOTE

The functions that can be set vary depending on the chosen service.

- 8 Read and confirm the displayed list of functions you have chosen, and then press *OK*.
- 9 Press *OK* to save your Shortcut.

NOTE

The Shortcut name will be assigned automatically. To change the Shortcut names, see *How to edit Shortcut Names* on page 29.

How to change Shortcuts

Web Connect Shortcuts cannot be changed. Instead, delete the Shortcut (see *How to delete Shortcuts* on page 29) and create a new Shortcut (see *Adding Web Connect Shortcuts* on page 28).

How to edit Shortcut Names

- 1 Press and hold the Shortcut until the dialog box appears:

NOTE

You can also press , then All Settings, and then press Shortcut Settings.

- 2 Press Edit Shortcut Name.
- 3 To edit the name, hold down  to delete the current name, and then enter a new name using the keyboard on the Touchscreen.
Press OK.

How to delete Shortcuts

- 1 Press and hold the Shortcut until the dialog box appears:

NOTE

You can also press , then All Settings, and then press Shortcut Settings.

- 2 Press Delete to delete the Shortcut that you chose in step 1.
Press Yes to confirm.

How to recall Shortcuts

The Shortcut settings are displayed on the Shortcut screen. To recall a Shortcut, press the Shortcut name.

Error messages

As with any sophisticated office product, errors may occur. If an error occurs, your machine will display an error message. The most common error messages are shown below.

You can correct most errors yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at <http://solutions.brother.com/>.

Error Message	Cause	Action
(For MFC-J2510/J4510DW) Network connection failed. Verify that the network connection is good. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Network connection failed. Verify that the network connection is good.	The machine is not connected to a network.	■ Verify that the network connection is good. ■ If the Web button was pressed soon after the machine was turned on, the network connection may not have been established yet. Wait and try again.
(For MFC-J2510/J4510DW) Connection failed to server. Check network settings. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Connection failed to server. Check network settings.	Network or server settings are incorrect. There is a problem with the network or server.	■ Confirm that network settings are correct, or wait and try again later. ■ If the Web button was pressed soon after the machine was turned on, the network connection may not have been established yet. Wait and try again.
(For MFC-J2510/J4510DW) Connection failed to server. Wrong Date&Time. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Connection failed to server. Wrong Date&Time.	Date and time settings are incorrect.	Set the date and time correctly. Note that if the machine's power cord is disconnected, the date and time settings may be incorrect.
(For MFC-J2510/J4510DW) Authentication is invalid. Reissue temporary ID, and register account again. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Authentication is invalid. Reissue temporary ID, and register account again.	The machine's authentication information (needed to access the service) has expired or is invalid.	Apply for Brother Web Connect access again to receive a new temporary ID, and then use the new ID to register the account to the machine (see <i>How to apply for Brother Web Connect access</i> on page 6 and <i>How to register and delete accounts on the machine</i> on page 8).

Error Message	Cause	Action
(For MFC-J2510/J4510DW) Failed to upload. Unsupported file or corrupt data. Confirm data of file. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Failed to upload. Unsupported file or corrupt data. Confirm data of file.	There is a problem with the file you are trying to upload, such as one of the following: ■ The file exceeds the service's limit on number of pixels, file size, etc. ■ The file type is not supported. ■ The file is corrupted.	The file cannot be used.
(For MFC-J2510/J4510DW) Service temporarily unavailable. Try again later. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Service temporarily unavailable. Try again later.	There is a problem with the service and it cannot be used now.	Wait and try again. Try accessing the service from a computer to confirm whether it is available or not.
(For MFC-J2510/J4510DW) Incorrect PIN code. Enter PIN correctly. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Incorrect PIN code. Enter PIN correctly.	The PIN registered to the machine is incorrect. The PIN is the four-digit number that was entered when registering the account to the machine.	Enter the correct PIN.
(For MFC-J2510/J4510DW) Incorrect or expired ID. Or this temporary ID is already used. Enter correctly or reissue temporary ID. Temporary ID is valid for 24 hours after it is issued. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Incorrect or expired ID. Or this temporary ID is already used. Enter correctly or reissue temporary ID. Temporary ID is valid for 24 hours after it is issued.	The temporary ID that was entered is incorrect. The temporary ID that was entered has expired. A temporary ID is valid for 24 hours.	Enter the correct temporary ID. Apply for Brother Web Connect access again and receive a new temporary ID, and then use the new ID to register the account to the machine (see <i>How to apply for Brother Web Connect access</i> on page 6 and <i>How to register and delete accounts on the machine</i> on page 8).

Error Message	Cause	Action
(For MFC-J2510/J4510DW) Display name has already been registered. Enter another display name. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Display name has already been registered. Enter another display name.	The name entered as the display name has already been registered.	Enter a different display name.
(For MFC-J2510/J4510DW) Max Qty of accounts reached. Try again after deleting unnecessary accounts. (For DCP-J4110DW, MFC-J4410DW/J4610DW) Max Qty of accounts reached. Try again after deleting unnecessary accounts.	The maximum number of accounts (10) have already been registered.	Delete any unnecessary accounts and try again.
(For MFC-J2510/J4510DW) Account is invalid. Please register account and shortcut again after deleting this shortcut.	The shortcut cannot be used because the account was deleted after the shortcut was registered.	Delete the shortcut, and then register the account and shortcut again.

brother®

**Visit us on the World Wide Web
<http://www.brother.com/>**



www.brotherearth.com