

picture 1



After you switch on the main switch picture 1 appears.




If you press the stop button the sewing machine will be initiated and ready for operation and then picture 2 appears.




picture 2

- corner knife.correction
- seam beginn
- seam length
- docking point
- corner knife correction
- seam end





- sewing programm
- active seam
- seam - name
- active seam function
- piece counter / per day





- one level down
- corner knife correction
- enter the seam length
- photocell correction
- upper thread-catcher / cutter
- without function
- Pick up function test
- One step back








level (1) sewing sequence






F1 sewing sequence: There you can put different seams together into one sewing program.

level (1) sewing functions



F2 sewing functions: There you can switch the different additional options from the current chosen seam on or off. The symbols which are deposited in black are in the current sewing in function.


level (1) sewing parameter




F3 sewing parameter: Sewing parameter give values which are effective in the current activated seam. If changes will be made, they have no effect on the other seams.

level (1)

basic parameter




Press




F4 basic parameter: Basic parameter give values which are effective in all seams. If changes will be made, they have effect on all the other seams.

level (1)

init parameter




Press



F5 init parameter: In the level init parameter different functions can be executed.

level (2)



F1-put in program name,
There you can put in a name for the current chosen seam.

F2- copy from program no.,
There you can copy a copy of another program on the current chosen seam.



F3- e-prom basic parameter,
There you can use sample program from the sewing memory.

F5- delete the program,
They you can delete the current seam.

F6- memory - chip ,
There you can read in and read out sewing programs and format program dongle (external memory chip).

level (1)



other



F6 other: On button F6 there are more functions and tests deposed, which supports to localize the malfunctions.

level (2)


I / O test



F1 I/O test: With the I/O test, you can check the inputs (switch and photocell) and also the outputs (valve).


level (2)

diagnostic



F2 diagnostic: Behind the level there are diagnostic programs which serve for localization of malfunctions.

level (3)



F1-service test ,

These tests can only be made by producer with special auxiliary equipment.

F2- sewing motor. ,

There can be made a function test of sewing motor, thread cutter and internal transmitter of sewing motor.

Furthermore you can read in the parameter for sewing motor.

F3- clamp motor ,

There can be made a function test for clamp motor.

F4- centre knife motor ,


There can be made a function test for centre knife motor.

F5- stacker motor ,


There can be made a function test for stacker motor.

level (2)

service code



Press





F3 service code:

With the service code you can unlock or lock different user levels.

- without code you can't change the sewing programs.
- with code „99160“ you can change the parameters and activate all test programs.
- with code „_____“ you can make software updates and such tests which can be made **only by specialized staff.**

(in case of need please contact A-S-S and ask for this code!)



F4 supplemental programs: With supplemental programs you can make updates and quantity limitation, select languages and count pieces.

F1- system update ,

Here you can read in a „newer“ software if A-S-S confirm that this is possible. You can also read in a software from another machine type to use the display on another machine.

(ONLY AFTER TALKING TO A-S-S!)

F2- select languages,

Here you can select the language. You can choose the relevant language by pressing the button F1- F6.


F3 pieces counter ,


Here you can see the number of pieces which you have already sewed.

F4- unlock codes ,

Here can be made quantity limitation.

THIS CAN ONLY BE MADE BY A-S-S!





Different operating languages you may choose is departing on present installed Software.

A-S-S
Automated Sewing Systems
Made in Germany

A-S-S Automated Sewing Systems AG
Am Beelacker 3
D-63856 Bessenbach
Germany

Phone: +49 (0) 6065 99233-0
Fax: +49 (0) 6065 99233-20

E-Mail: info@assag.de
Internet: www.assag.de

Basic-Parameter list BASS 3050

01:	Loading Position Front	=	135	mm
02:	Loading Position Middle	=	225	mm
03:	Loading Position Rear	=	315	mm
04:	Patch Guide UP Aft.Sew	=	320	mm
05:	Full Bobb.Thread Length	=	057	m
06:		=		
07:		=		
08:	Clamp Automatic Down	=	0.0	sec
09:	Time After Clamp Down	=	0.2	sec
10:		=		
11:	ST.ARM SWINGS-> CLAMP	=	0.0	sec
12:	ST.CLAMP-> ST.ARM BACK	=	0.0	sec
13:	STACKER CLAMP OPEN ...	=	0.0	sec
14:		=		

15:		=		
16:	Carriage Return	=	0.2	sec
17:		=		
18:	Thread Pickup Release	=	0.15	sec
19:	Thread Clamp Duration	=	0.04	sec
20:		=		
21:	Needle Thread Trim Pos	=	0.07	sec
22:	Durat.Needle Trim Knife	=	0.14	sec
23:	Carriage Tab Cut Dist.	=	154	mm
24:	Carriage Speed Tab Cut	=	50	%
25:	Tab Knife Start	=	118	mm
26:	Tab Knife Cutting Time	=	0.2	sec
27:	Clamps UP	=	0.4	sec
28:	Pick Up Work Piece ...	=	0.5	sec

29:		=		
30:		=		
31:	Carriage Speed	=	99	%
32:	Sequence In Step	=	00	
33:	Bobb.Thrd.Photoc.On/Off	=	01	
34:	Trimming Speed	=	300	Rpm
35:	Trimming Posit.(00..59)	=	00	min
36:	Bobbin Trimm. Duration	=	0.12	sec
37:		=		
38:		=		
39:		=		
40:	Second Photocell	=	00	


Seam-Parameter list BASS 3050

```
01: LOADING POSIT ADJUSTM. = 225 mm
02: CLAMP MOVE IN SPEED .. = 60 %
03: SPEED SEAM BEGIN ..... = 1600 RPM
04: SPEED MAIN SEAM ..... = 2300 RPM
05: SPEED SEAM END ..... = 1600 RPM
06: DISTANCE STARTING SPEED = 05 mm
07: DISTANCE END SPEED .. = 05 mm
08: STITCHLENGTH SEAM BEGIN = 1.5 mm
09: STITCHLENGTH MAIN SEAM = 2.6 mm
10: STITCHLENGTH SEAM END = 1.5 mm
11: DIST. STITCHLENGTH START = 05 mm
12: DIST. STITCHLENGTH END = 05 mm
13: TACK LENGTH SEAM BEGIN = 08 mm
14: TACK LENGTH SEAM END = 08 mm
```

```
15: =
16: =
17: CENTER KNIFE ENGAGE .. = 18 mm
18: CENTER KNIFE DISENGAGE = 00 mm
19: THREAD MONITOR ON AFTER = 30 mm
20: THREAD MONITOR FILTER = 07 mm
21: =
22: =
23: =
24: INTERIM STOP SELECT+POS = 00 cm
25: PICK UP PART SELECT+POS = 00 cm
26: CENTER KNIFE MOT. SPEED = 75 %
27: =
28: STACKER POSITION ..... = 00 cm
```

```
29: =
30: FLAP CLAMPS MODE ..... = 04
31: FOLDING SLIDE MODE ... = 03
32: VACUUM MODE ..... = 03
33: MAIN CLAMP MODE ..... = 00
34: =
35: STACKER MODE ..... = 03
36: =
37: =
38: =
39: =
40: =
```

Input / Output BASS 3050



X2	Functional role	Signal/ black	+ 24 V / brown 21 - 25	GND blue 14 - 20
S2	clamp 0-position	Pin 02	Pin 21-25	Pin 14-20
S7	folder down	Pin 04	Pin 21-25	Pin 14-20
S15	photocell flap	Pin 11	Pin 21-25	Pin 14-20
S20	foot switch	Pin 06		Pin 14-20

X3	Functional role	Signal/ white	+ 24 V / brown 14 - 25
Y01	thread cutter	Pin 01	Pin 14-25
Y02	thread catcher	Pin 02	Pin 14-25
Y03	thread movable	Pin 03	Pin 14-25
Y04	center knife down	Pin 04	Pin 14-25
Y05	center knife lock to cut	Pin 05	Pin 14-25
Y06	folder down	Pin 06	Pin 14-25
Y07	folder up	Pin 07	Pin 14-25
Y08	dart stretcher	Pin 08	Pin 14-25
Y09	vacuum	Pin 09	Pin 14-25
Y11	stacker (pan bar)	Pin 10	Pin 14-25
Y13	corner knife (seam begin)	Pin 11	Pin 14-25
Y14	corner knife (seam end)	Pin 12	Pin 14-25

X4	Functional role	Signal/ white	+ 24 V / brown 09 - 15
Y18	flap clamp right	Pin 01	Pin 09-15
Y19	flap clamp left	Pin 02	Pin 09-15
Y20	folding slide left+right	Pin 03	Pin 09-15
Y22	mainclamp right	Pin 05	Pin 09-15
Y23	mainclamp left	Pin 06	Pin 09-15
Y24	mainclamp pressure supply	Pin 07	Pin 09-15
Y58	fabric clamp pick up	Pin 08	Pin 09-15