

PARTS CATALOGUE

FOR

MODEL VX540 and VX560

**Please clarify Ref. No. and
Parts No. as well as parts name
When you place an order.**

REF. NO.	PARTS NO.	PARTS NAME	REF. NO.	PARTS NO.	PARTS NAME
1	128405002	Face plate	41	009669314	Screw
2	120094001	Face plate hinge	42	125269001	Tension disc
3	117838001	Washer	43	125270001	Tension disc
4	009670812	Screw	44	125302001	Tension releaser, B
5	123516001	Face plate spring	45	125275001	Spring
6	002670612	Screw	46	125271001	Tension spring
7	128437000	Presser bar	47	125272009	Tension control knob assembly
8	120124001	Presser bar spring	48	125274000	Tension control ring
9	102445000	Presser bar guide bracket	49	125273009	Tension control knob
10	100058003	Screw	50	120329001	Tension control knob stopper
11	125465001	Presser foot assembly	51	110735001	Washer
12	106120001	Thumb screw	52	021680202	Nut
13	121197001	Tension releaser spring bracket	53	120336001	Thread take-up spring cover
14	102538007	Screw	54	120337001	Thread take-up spring
15	121196001	Spring	55	120436002	Thread take-up spring case, B
16	125473001	Tension releaser, A	56	120435002	Thread take-up spring case, A
17	128599001	Needle bar supporter	57	120265001	Spring washer
18	120102001	Needle bar supporter stud	58	120335002	Stud screw
19	048050342	Stop ring	59	125165001	Presser foot lifter
20	002680712	Screw	60	102037001	Stud screw
21	125429001	Needle bar	61	201434000	Sew-light bulb
22	123185001	Screw	62	139238001	Sew-light assembly
23	120110001	Spring	63	120369001	Sew-light holder
24	128391001	Needle bar thread guide	64	103386002	Screw
25	100139001	Screw	65	002680712	Screw
26	121496001	Needle clamp assembly	66	128412001	Cord guide plate
27	100028014	Needle #14	67	002670612	Screw
28	123143001	Needle plate	68	120679001	Cord holder B
29	124610003	Upper plate	69	002670612	Screw
30	116588001	Needle plate spring, L	70	110452001	Cord supporter
31	116587001	Needle plate spring, R	71	122243001	Washer
32	125139001	Screw	72	113322001	Nut
33	009671014	Screw	73	117520001	Sew-light switch knob
34	120339001	Thread guide	74	102716003	Screw
35	120340001	Thread guide	75	105433001	Eccentric stud
36	102538007	Screw	76	123597001	Zigzag connecting rod
37	102538007	Screw	77	123600000	Roller
38	128551001	Thread guard assembly	78	124503002	Spring
39	128552001	Thread guard body	79	048030342	Stop ring
40	125732001	Thread guide assembly	80	128510001	Frame assembly


REF. NO.	PARTS NO.	PARTS NAME	REF. NO.	PARTS NO.	PARTS NAME
81	129102001	Control frame body	121	123624001	Z Finger frame
82	128480001	Zigzag adjusting lever	122	123628001	Z Finger frame shaft
83	129106001	Zigzag link assembly	123	048030342	Stop ring
84	009680612	Screw	124	048050342	Stop ring
85	028680243	Washer	125	123625001	Z Finger assembly
86	123589001	Zigzag width control plate	126	123631001	Finger assembly
87	025660132	Washer	127	123638001	Z Adjusting arm
88	124303001	Washer	128	021660102	Nut
89	009660613	Screw	129	103978002	Screw
90	123584001	Dial stopper	130	025350332	Washer
91	123586001	Spring washer	131	009670812	Screw
92	048040342	Stop ring	132	100043003	Screw
93	128511001	Stitch regulating dial shaft	133	100042002	Stop motion knob
94	002680712	Screw	134	100041002	Stop motion knob washer
95	025060132	Washer	135	128436003	Balance wheel
96	048040342	Stop ring	136	120438001	Pin
97	002680712	Screw	137	122422000	Balance wheel bushing
98	048060342	Stop ring	138	120031000	Upper shaft bushing, R
99	128515001	BH Feed cam	139	120985001	Upper shaft
100	128579001	BH Feed control cam	140	122424000	Feed arm
101	128513000	Pattern cam assembly	141	122425000	Balance
102	123616001	Washer	142	122412001	Balance holder
103	124537001	Washer	143	002670612	Screw
104	123615000	Pattern cam shaft	144	151604001	Screw
105	048030342	Stop ring	145	123601000	Worm
106	123608001	Feed control cam rod	146	151602001	Screw
107	128508001	Feed adjusting arm	147	128533000	Collar
108	002680512	Screw	148	101706001	Screw
109	048030342	Stop ring	149	120032000	Upper shaft bushing, L
110	125586001	Spring	150	106629002	Screw
111	009671013	Screw	151	124614000	Eccentric counter weight
112	025350132	Washer	152	100018002	Screw
113	128519001	Finger shaft assembly	153	100251001	Screw
114	123637001	Finger shaft	154	101706001	Screw
115	128521001	Finger frame	155	117752001	Thread take-up lever assembly
116	123633001	Finger frame shaft	156	100058003	Screw
117	048030342	Stop ring	157	120582001	Needle bar crank
118	123634001	Release lever	158	120580001	Needle bar crank rod assembly
119	009630813	Screw	159	123736000	Needle bar crank rod
120	021630103	Nut	160	120108001	Needle bar clamp stud

REF. NO.	PARTS NO.	PARTS NAME	REF. NO.	PARTS NO.	PARTS NAME
161	120109001	Needle bar clamp	201	113431002	Washer
162	100253001	Flat head screw	202	128506001	Spring
163	120106001	Felt	203	128507001	Collar
164	120107001	Spring	204	025680232	Washer
165	100366002	Screw	205	102571003	Nut
166	100507000	Metal plate	206	123683002	Top cover
167	123643001	Feed regulation lever	207	009681214	Screw
168	123645001	Adjusting screw	208	170226000	Spool pin assembly
169	102571003	Nut	209	120347029	Spool pin stand
170	124454001	Stud screw	210	116480001	Washer
171	123646001	Spring	211	104269001	Spool pin
172	128522001	Z Selecting lever assembly	212	103366001	Felt
173	048040342	Stop ring	213	009670514	Screw
174	123669001	Spring	214	123512001	Screw
175	123659001	Release lever	215	101552002	Screw
176	002680712	Screw	216	121846001	Bobbin presser
177	123660001	Release lever shaft	217	124243001	Oil through
178	124616000	Washer	218	124246001	Stop ring
179	124615001	Forked connecting rod	219	124466001	Bobbin winder assembly
180	115234001	Slide block assembly	220	124467001	Bobbin winder bracket assembly
181	100067001	Slide block stud	221	125928000	Spring
182	100066001	Slide block	222	120448001	Bobbin winder rubber ring
183	124617001	Stud	223	123661001	Spring
184	048050342	Stop ring	224	120263001	Stud screw
185	118519001	Washer	225	128411003	Rear cover assembly
186	124629001	Crank rod assembly	226	124563003	Rear cover
187	124630001	Crank rod	227	188595001	Spring
188	002681212	Screw	228	188592001	Feed regulating lever arm
189	123547000	Feed regulator stud	229	048040342	Stop ring
190	125719000	Feed regulator	230	123526005	Feed regulating lever
191	123554002	Spring	231	047201242	Spring pin
192	123548001	Feed regulator adjusting plate	232	102538007	Screw
193	002681212	Screw	233	122179001	3P Socket cover
194	103978002	Screw	234	002301605	Screw
195	021660102	Nut	235	122178001	3P Socket body
196	128502001	Feed regulating bar assembly	236	122373000	Screw
197	120258001	Screw	237	021300106	Nut
198	021670102	Nut	238	009711012	Screw
199	103813001	Washer	239	025710132	Washer
200	048030342	Stop ring	240	122372000	Contact pin

REF. NO.	PARTS NO.	PARTS NAME	REF. NO.	PARTS NO.	PARTS NAME
241	124661003	Motor cover	277	128529001	Pattern selecting dial plate for VX560
242		Model mark	278	128463000	Lower shaft bushing, R
243	102538007	Screw	279	124631001	Lower shaft crank assembly
244		Controller complete	280	124632001	Lower shaft crank
245	000711212	Screw	281	009681212	Screw
246	124628001	Washer	282	120990001	Screw
247	124575001	Adle pulley assembly	283	124633000	Lower shaft
248	128559001	Adle pulley bracket	284	128464000	Lower shaft bushing, L
249	202418000	Washer	285	151604001	Screw
250	124579000	Adle pulley	286	106105001	Screw
251	048040342	Stop ring	287	101706001	Screw
252	124656001	Spring	288	139092002	Lower shaft bevel gear
253	107657003	Spring hanger	289	125429001	Feed dog
254		Motor complete	290	100080003	Screw
255	125605001	Screw	291	102927000	Pin
256	110071002	Washer	292	503154001	Spring
257	025710232	Washer	293	120998001	Spring hanger
258	124636000	Belt	294	116605001	Taper point stud
259	124637000	Belt	295	120990001	Screw
260	122155001	Cord guide plate	296	120994001	Horizontal feed rocking shaft assembly
261	002670612	Screw	297	120996000	Feed bar
262	124635001	Cord supporter	298	120997000	Feed bar hinge shaft
263	002670612	Screw	299	100366001	Screw
264	124537001	Washer	300	120995000	Horizontal feed rocking shaft
265	128524001	Z Selecting cam for VX540	301	048040342	Stop ring
	128530001	Z Selecting cam for VX560	302	139057001	Horizontal feed shaft arm assembly
266	009670512	Screw	303	139058000	Horizontal feed shaft arm
267	128525001	Feed selecting cam for VX540	304	009681212	Screw
	128531001	Feed selecting cam for VX560	305	120990001	Screw
268	128500002	Arm panel assembly for VX540	306	102436001	Taper point stud
	128526002	Arm panel assembly for VX560	307	124622004	Drop feed knob
269	139112002	Adjusting knob	308	124730001	Spring washer
270	139111000	Washer	309	124627001	Drop feed lever, A
271	025660236	Washer	310	025350332	Washer
272	002660802	Screw	311	002670612	Screw
273	002670812	Screw	312	124621001	Drop feed lever, B
274	048050342	Stop ring	313	108790002	Stud screw
275	128492001	Pattern selecting dial shaft	314	009670512	Screw
276	128487001	Pattern selecting dial	315	025350132	Washer
277	128523001	Pattern selecting dial plate for VX540	316	124618001	Drop feed connecting link

REF. NO.	PARTS NO.	PARTS NAME	REF. NO.	PARTS NO.	PARTS NAME
317	045161260	Cutter pin	357	128477001	Stud screw
318	121013000	Drop feed adjusting shaft	358	128476001	Spring
319	121015001	Stopper	359	122250001	Set lever, L
320	002670612	Screw	360	122249001	Set lever, R
321	120990001	Screw	361	122977001	Washer
322	139060001	Guide ring	362	128471001	Shuttle race ring
323	128457001	Washer	363	102927000	Pin
324	139062001	Spring	364	128469001	Shuttle race body
325	139059001	Vertical feed lever	365	128473001	Shuttle race top spring
326	121007001	Screw	366	125514001	Screw
327	121001001	Vertical feed arm assembly	367	139096001	Collar
328	139061001	Vertical feed shaft	368	013680412	Screw
329	048050342	Stop ring	369	121024001	Shuttle driver shaft bevel gear
330	124639001	Vertical feed cam assembly	370	101706001	Screw
331	124640000	Vertical feed cam	371	118804001	Screw
332	100251001	Screw	372	116577001	Cover
333	128418002	Accessory table assembly	373	139100001	Bevel gear cover
334	128419002	Accessory table	374	002670612	Screw
335	124426001	Rubber cushion	375	123768001	Hinged door spring
336	128423001	Guide pin, B	376	100242003	Screw
337	013679412	Screw	377	128416001	Hinge plate
338	128424001	Accessory table stand	378	125985003	Hinged door
339	128427001	Hinge pin	379	124608003	Cleaning cover
340	125775001	Spring washer	380	128417002	Base plate
341	025050132	Washer	381	122995001	Machine number plate
342	048040342	Stop ring	382	116231001	Pin
343	128420001	Guide pin, A	383	124688001	Rubber cushion for base plate
344	128428001	Washer	384	122110001	Washer
345	104354003	Shuttle hook	385	002660503	Screw
346	128478001	Bobbin	386	000711212	Screw
347	125980002	Bobbin case assembly	387	124242001	Washer
348	125918002	Bobbin case	388	128429001	Spring
349	125921001	Tension spring	389	009680612	Screw
350	100116001	Screw	390	025680232	Washer
351	121007001	Screw	391	124657001	Cap
352	139093001	Shuttle driver assembly	392		VX Model mark
353	139094001	Shuttle driver	393	047250850	Spring pin
354	122429001	Shuttle driver spring	394	123513000	Spring pin
355	121632001	Screw	395	013689412	Screw
356	139097001	Shuttle race assembly	396	128472001	Pin

MODEL VX540 and VX560



56.7.15

VX540, VX560
H9060155
Printed in Japan