



Mobile Print Guide for Brother iPrint&Label (Android™)



Before You Use Your Brother Label Printer

Definitions of Notes

We use the following symbol and convention throughout this User's Guide:



Tips icons indicate helpful hints and supplementary information.

Trademarks

Wi-Fi and Wi-Fi Direct are registered trademarks of Wi-Fi Alliance®.

The Bluetooth word mark is owned by the Bluetooth SIG, Inc. and any use of such marks by Brother International Corp. is under license.

Android and Google Play are trademarks for Google Inc. Use of these trademarks is subject to Google Permissions.

Any trade names and product names of companies appearing on Brother products, related documents, and any other materials are all trademarks or registered trademarks of those respective companies.

Table of Contents

1	Introduction.....	1
	Download Brother iPrint&Label Using the Google Play™ Store App.....	1
	Device Connections.....	1
	Icons	1
	Set Up Your Label Printer.....	2
	Set Label Size	2
2	Create Labels.....	3
	Create a Custom Label.....	3
	Create a Label Template	3
	Change the Font.....	3
	Change the Label Size	3
3	Save Labels.....	4
	Save a Label	4
	Open a Saved or Previously-printed Label	4
	Delete Saved or Previously-printed Labels	4
4	Print Labels.....	5
	Print a Label	5

1 Introduction

Download Brother iPrint&Label Using the Google Play™ Store App

Brother iPrint&Label enables you to easily print labels from your Android device to a Brother label printer.

Install Brother iPrint&Label from the Google Play™ Store app. For best results, make sure you are using the latest version.

Device Connections

Connect your mobile device to your Brother label printer using one of the following connection methods:






- USB
- Wi-Fi Direct®
- Wi-Fi®
- Bluetooth



Depending on your Brother label printer and mobile device, supported connection methods may vary.

To configure your Brother label printer, see your label printer's *Quick Setup Guide*. Download the *Quick Setup Guide* from your model's **Manuals** page on the Brother Solutions Center at <http://support.brother.com/manuals>.

Icons

Icon	Usage
	Settings
	Menu
	New Label
	Add Object
	Back Arrow

Set Up Your Label Printer

If a different label printer or if **Not connected** appears in the device list:

1. Tap  or tap **Settings**.
2. Tap **Printer**.
3. Select your label printer.




If your label printer is not listed, tap **Set Manually**, and then enter the label printer's IP address listed on the Printer Configuration report. To print the report, see your label printer's *User's Guide*. Download the *User's Guide* from your model's **Manuals** page on the Brother Solutions Center at <http://support.brother.com/manuals>.

4. When finished, tap the gray area to the right of the settings.

Set Label Size

Set the correct label size that is currently installed in the label printer.

1. Tap  or **Settings**.
2. Tap your label printer.
3. Do one of the following:
 - Tap **Size** and select the label size from the list.
 - Tap **Check Media** (if available for your label printer model).




If iPrint&Label cannot detect the label size, make sure that the label printer is turned on, the label roll is installed, and the label printer's cover is firmly closed.


4. When finished, tap the gray area to the right of the settings.

2 Create Labels

Create a Custom Label


1. Tap .
2. Type your label text and tap **Done**.
 - To exit the text window without entering or saving text, tap **Done**.
3. To add an object, such as text, a symbol, an image, a bar code, or another item, to the label, tap **+**.
4. Tap the object you want to add from the list.
 - To edit an object on the label, including text, double-tap the object.
 - To delete an object on the label, tap the object, and then tap **Delete**.

Create a Label Template

1. Tap the category you want, such as Address, Asset Management, or other.
2. Tap the label you want to edit.
 -  If a message about the label size appears, tap **OK**.
3. To add an object, such as text, a symbol, an image, a bar code, or another item, to the label, tap **+**.
4. Tap the object you want to add from the list.
 - To edit an object on the label, including text, double-tap the object.
 - To delete an object on the label, tap the object, and then tap **Delete**.

Change the Font


1. When the label is displayed, tap the text to select it.
2. Tap **Font** to change your label text's Style, Font, or other Properties.
3. When finished, tap the gray area above the font settings.

 Font options vary based on the label printer model you are using.

Change the Label Size

1. When the label is displayed, tap the label size, which appears as a measurement in the center of the bottom of your screen.

Example: 0.47" ▼

 Label size options vary based on the label printer model you are using.

2. Do one of the following:
 - Tap **Size** and select the label size from the list.
 - Tap **Check Media** (if available for your label printer).
3. When finished, tap **OK**.

3 Save Labels

Save labels to reuse, edit, and print again.



Save a Label

1. To save the label that you are creating, tap **Save**.
2. Type a label name in the **Save As...** field, and then tap **Save**.

Open a Saved or Previously-printed Label

1. Tap **My Labels**.
2. Do one of the following:
 - Under **Saved Labels**, tap the previously-saved label you want.
 - Under **Print Log**, tap the previously-printed label you want.

Delete a Saved or Previously-printed Labels


1. Tap .
2. To delete one or a few specific labels, tap **Select**.
3. Tap the label(s) you want to delete.
4. Tap **Delete**, and then tap **OK**.
 - To delete all saved or previously-printed labels, tap **Delete All**, and then tap **OK**.
 - To exit without deleting, tap .

4 Print Labels

Print a Label

1. To print the label that you are creating, tap **Print**.
2. Change the print settings you want, including number of Copies, Cut Options, and other options... (tap the down arrow to display additional Print options).
3. Tap **Print**.



To exit without printing, tap .



Visit us on the World Wide Web
<http://www.brother.com>



ENG
Version A