

BE-438F Recommendable Parts List

Parts Code	Parts Name	Q'ty
SB1060001	NEEDLE BAR THREAD GUIDE B	1
SA6193001	THREAD TAKE-UP SPRING C	1
152686201	SHUTTLE RACE BASE, B	1
152690501	BOBBIN CASE ASSY, B	1
154340101	TENSION SPRING	1
SA1882001	SHUTTLE HOOK ASSY_ W_BOX152687	1
152777001	WORK CLAMP (RIGHT)	1
152778001	WORK CLAMP (LEFT)	1
153608101	WORK CLAMP (RIGHT)	1
154527001	WORK CLAMP (LEFT)	1
S49694001	WORK CLAMP_ F-L	1
S49695001	WORK CLAMP_ F-R	1
SA6509001	WORK CLAMP RF	1
SA6510001	WORK CLAMP LF	1
SA3378001	FEED PLATE,DENIM	1
SA3607001	FEED PLATE,L	1
SA3609001	FEED PLATE,F	1
SA6511201	FEED PLATE F 6X23	1
SB0949001	Needle Hole Plate 2.4mm	1
SB0715001	Needle Hole Plate 1.6mm	1
SB0951001	Needle Hole Plate 1.6mm	1
SB0713001	BOBBIN THREAD CLAMP SPRING	1
100360003	SCREW 2.38	2
SB1275001	GREASE UNIT	1
SB0347001	RESOLVER STATOR 430 ASSY	1
SA9525001	MAIN PCB ASSY	1
SA8350001	MOTOR PCB ASSY	1
SA9500001	POWER PCB ASSY	1