


Using Nozzle Clean to Inspect Maintenance Parts





1. Start at main menu, scroll down to “Maintenance”.



2. Press OK.
3. Scroll down to “Nozzle Cleaning”, press OK; then follow instructions on the screen.



4. Open the front cover to inspect the maintenance parts.
5. Manually move the carriage to give your room to inspect the machine.
6. Inspect wiper blades, caps, flushing plate, fan filter, rail felt(s), and wiper cleaner (Pick the right edge of the Wiper Cleaner and move slightly to the right (1-2 mm) by your right hand, the claw in the right will be released. Move the Wiper Cleaner slightly to the left (1-2 mm) to release the claw in the left.).



7. If any of these parts looked soiled, follow the instructions for parts replacement.

Your dealer(s)-distributor(s) are your first line of support, please contact them for prompt assistance. If you do not have a dealer(s)-distributor(s) refer to our website <http://www.brother-usa.com>. For additional information contact Technical Support at 1-877-427-6843 or tsupport@brother.com. Any information within this document is subject to change.
